



Anleitung F3A Antrieb Adverrun / User manual F3A Drive Adverrun

2 / 3 Blade Propeller and Spinner Manual

Propeller preparation

Front propeller

Locate the longer propeller blades and assemble with the smaller propeller hub. Pay attention to the propeller hub orientation (see pictures below). Tighten screws so that you feel resistance moving the blades by hand.

Adverrun Propellers have been designed to allow only minimal movement to prevent propeller collisions. We check assembly before delivery but due to production tolerances there may be cases where propeller blades require a bit of sanding to fit the hub. In such a case you are able to identify the contact area of blade and hub by holding the assembly against a light.



Rear propeller

Locate the shorter propeller blades and assemble with the larger propeller hub. Pay attention to the propeller hub orientation (see pictures below). Tighten screws so that you feel resistance moving the blades by hand.



Final assembly

Mount the rear propeller as shown in the left picture below. Use the M16 washer and the propeller nut that came with the Advverrun Drive.

Mount the front propeller as shown in the right picture below. Use the prop collet and M8 nut that came with the Advverrun drive.

